

How to find us

SCHOTT GlasMuseum SCHOTT Villa in Jena

SCHOTT GlasMuseum

Otto-Schott-Strasse 13
07745 Jena
Germany

Phone.: +49(0)36 41/6 81-7 65 (SCHOTT GlasMuseum)

Phone.: +49(0)36 41/6 81-7 54 (SCHOTT Villa)

Fax: +49(0)36 41/6 81-7 56

E-Mail: museum@schott.com

www.schott.com/museum

Opening times:


Tuesday - Friday: 1 pm - 6 pm

Group tours can be arranged
outside of the normal opening times

Admission free

Bus parking available

SCHOTT GlasMuseum
and SCHOTT Villa are accessible to wheel-chair users



SCHOTT
glass made of ideas

By rail:

From the direction of Frankfurt am Main:

With the InterCity Express (ICE) or InterCity (IC) via Fulda – Eisenach – Erfurt – change in Weimar to the Regional Railroad (Regionalbahn or RB) in the direction of Gera – get off at Jena-West station.

From the direction of Berlin:

With the InterCity Express (ICE) or InterCity (IC) via Wittenberg – Leipzig – Naumburg (Saale) – get off at Jena-Paradies station.

From the direction of Hamburg:

With the InterCity Express (ICE) or InterCity (IC) via Hannover – Göttingen – change in Kassel-Wilhelmshöhe to the InterRegio (IR) in the direction of Erfurt – Eisenach – Erfurt – change in Weimar to the Regional Railroad (Regionalbahn or RB) in the direction of Gera – get off at Jena-West station.

From the direction of Düsseldorf:

With the InterRegio (IR) to Erfurt via Duisburg – Essen – Dortmund - Hamm (Westfalen) – Paderborn – Kassel-Wilhelmshöhe – Eisenach – change in Erfurt to the Regional Railroad (Regionalbahn or RB) in the direction of Gera – Weimar – get off at Jena-West station.

Or with the InterCity Express (ICE) or InterCity (IC) via Cologne (Köln) – Bonn – Koblenz – Frankfurt am Main etc.

From the direction of Munich

With the InterCity Express (ICE) or InterCity (IC) via Augsburg – Würzburg – change in Fulda – Eisenach – Erfurt – change in Weimar to the Regional Railroad (Regionalbahn or RB) in the direction of Gera – get off at Jena-West station.

By car or bus:

From the direction of Frankfurt am Main (approx. 290 km):

Autobahn A 5 in the direction of Kassel, Hannover, Hamburg – at the Kirchheim junction (Kirchheimer Dreieck) turn right onto Autobahn A 4 in the direction of Erfurt, Dresden – Eisenach – Erfurt – Weimar – Jena-Göschwitz exit – direction Jena Stadtmitte – in Jena follow the signs to "SCHOTT GlasMuseum".

From the direction of Berlin (approx. 260 km):

Autobahn A 9 in the direction of Leipzig, Nürnberg, München – Dessau – Leipzig – at the Hermsdorf junction (Hermsdorfer Kreuz) turn off onto Autobahn A 4 in the direction of Erfurt, Frankfurt am Main – Jena-Lobeda exit – direction Jena Stadtmitte – in Jena follow the signs to "SCHOTT GlasMuseum".

From the direction of Hamburg (approx. 470 km):

Autobahn A 7 in the direction of Hannover, Kassel, Frankfurt am Main – at the Hannover-Ost junction (Autobahnkreuz Hannover-Ost) turn off onto Autobahn A 2 in the direction of Magdeburg, Berlin – at the Magdeburg junction (Autobahnkreuz Magdeburg) turn off onto Autobahn A 14 in the direction of Leipzig, Dresden – at the Schkeuditz junction (Schkeuditzer Kreuz) turn off onto Autobahn A 9 in the direction of Nürnberg, München – at the Hermsdorf junction (Hermsdorfer Kreuz) turn off onto Autobahn A 4 in the direction of Erfurt, Frankfurt am Main – Jena-Lobeda exit – direction Jena Stadtmitte – in Jena follow the signs to "SCHOTT GlasMuseum".

From the direction of Düsseldorf (approx. 440 km):

Autobahn via Köln – at the Köln-Ost junction (Autobahnkreuz Köln-Ost) onto Autobahn A 4 – at the Olpe-Süd junction (Autobahnkreuz Olpe-Süd) turn off onto Autobahn A 45 in the direction of Gießen – at Wetzlar-Ost exit turn off onto Europastrasse E 40 – at the Reiskirchen junction (Reiskirchener Dreieck) turn off onto Autobahn A 5 in the direction of Kassel, Hannover – at the Kirchheim junction (Kirchheimer Dreieck) turn off onto Autobahn A 4 in the direction of Erfurt, Dresden – Eisenach – Erfurt – Weimar – Jena-Göschwitz exit – in the direction of Jena Stadtmitte – in Jena follow the signs to "SCHOTT GlasMuseum".

From the direction of Munich (approx. 370 km):

Autobahn A 9 in the direction of Nürnberg, Leipzig, München – Dessau – Leipzig – at the Hermsdorf junction (Hermsdorfer Kreuz) turn off onto Autobahn A 4 in the direction of Erfurt, Frankfurt am Main – Jena-Lobeda exit – direction Jena Stadtmitte – in Jena follow the signs to "SCHOTT GlasMuseum".